








CTUA Directory of Upgrade Assistance












 = manual available

Upgrade Assistance #	Drive (Part Numbers)
CTUA001	AccuSpeed (51XXX and 51XX-XX)
CTUA002 	Prism (2950-800X)
CTUA003 	Laser (2950-8XXX Laser 1 & 2) (6150-80XX Laser 3)
CTUA004 	Eclipse (6230-800X)
CTUA005 	Horizon (2990-800X)
CTUA006 	ES2300RG (2300-810X)
CTUA007 	ES2600RG (2600-800X and 2600-8075)
CTUA008 	ES2700 (2710-800X)
CTUA009 	Focus 1 (2400-800X)
CTUA010 	Focus 2 (2450-80XX)
CTUA011 	Focus 3 (F3#X#) ie F3N5C F3R2E
CTUA012 	Focus RG (6041-800X)
CTUA013 	Quantum II (9500-8XXX)
CTUA014 	Spectrum (2200-84XX)
CTUA015 	VIP / ES-6060 (1700-8XXX and 1850-8XXX)
CTUA016 	AC Eagle (6230-8X0X)
CTUA017 	MicroVision (WMX1XX)
CTUA018 	Vision 1 (WA100X)
CTUA019 	Vision 2 (WA2XXX)
CTUA020 	Vision 3 (WAXXXX)
CTUA021	AS5100 (51XXX and 51XX-XX)
CTUA022 	MX (MX-XXX0-CE)
CTUA023 	Patriot (WAXXXX)
CTUA024 	ES220 (1110-XX)
CTUA025	ES222 (1310-XXX)
CTUA026	ES225 (1060-1600 pre 1979, 1060-224 1979 and later)
CTUA027 	DC Spirit Plus (WX8X0X)
CTUA028 	DC Spirit (WX8X0X)
CTUA029 	Commander CDII (CDXX0II)
CTUA030 	Commander CDS (CDSXX0)
CTUA031 	Commander CDE (CDEXXX0HP or CDLEXXX0HP)
CTUA032 	Commander CDE BS (CDEXXX0)

 = manual available

Upgrade Assistance #	Drive (Part Numbers)
CTUA033 	Commander GP (GPDXX0X or GPDXX0XLV)
CTUA034 	Commander SE (SEXXX0XXXX)
CTUA035 	Commander VCD (VCD55 VCD75 VCD150)
CTUA036 	Dinverter A (DIN1XX00XXA)
CTUA037 	Dinverter B (DIN3XX00XX0B)
CTUA038 	DigitAx (DBEXXX0 or DBXXX0)
CTUA039 	DominAx (DD75 through DDXX0)
CTUA040 	DynamAx (9600-0XXX)
CTUA041 	Large Vector (V1100 – VXX00)
CTUA042 	High HP CDE (UNI54XX or HPCDE)
CTUA043 	IMO Jaguar (CD75 – CDXX0 and CDL0X)
CTUA044 	Spindax (SA220 – SXXX0)
CTUA045 	Unidrive Classic (UNIXX0X)
CTUA046 	Vector (V75 – VXX0)
CTUA047 	Vector Bookshelf (VBXXXX)
CTUA048 	Mentor I (6MXX 6MS4QXXX 6MD4QXXX)
CTUA049	FXM3 / FXM4
CTUA050	ES60 (1250-XXX)
CTUA051	ES125 (1251-XX)
CTUA052 	ES220 (1110-XX)
CTUA053 	ES220RG (1175-800X or 1175-800XE)
CTUA054	ES222 (1310-XXXX)
CTUA055	ES225 (1060-XX)
CTUA056	ES300A (1020-XX)
CTUA057	ES300RG (1045-XX)
CTUA058	100ARG (990-XX)
CTUA059	150ARG (1082-XX)
CTUA060	367 Eddy Current Controller
CTUA061	1235 Eddy Current Controller
CTUA062 	S10 (S10XXX-9##)
CTUA063 	C10 (C10XXXX-1)
CTUA064 	CV10 (CV10XXXX-9X)
CTUA065 	GP10 (GP10XXXX-9)
CTUA066 	VG10 (VG10EXST3XXXX##)
CTUA067 	FP5 (CIMR-P5UXXXX)
CTUA068 	GP5 (CIMR-P5UXXXX)
CTUA069 	PC10 (PC10E1STXXXXX)
CTUA070 	VG7 (FRNXXVVG7S-2/4)
CTUA071	EZ-Start (EZS-40 through EZS-XXX0)

 = manual available

Upgrade Assistance #	Drive (Part Numbers)
CTUA072 	dcM6+
CTUA073 	dcM12+
CTUA074 	DC400 (SAF40X.XXXX)
CTUA075 	ACX10 (ACE10XVXP00XX##)
CTUA076 	ACX15 (ACE15XVXP00XXC)
CTUA077 	ACX20 (ACE20XV3P0XXXN1)
CTUA078 	ACX30 (ACE30XV3PXXXXVTXX)
CTUA079 	ACX40 (ACE40XV3PXXXXN1X)
CTUA080 	Mentor II
CTUA081 	Quantum III
CTUA082 	FXM5